

Display section with image of the cycling computer screen and descriptions for clock, signal, speed, battery, temperature, and mode. Includes icons for AM/PM, signal reception, speed unit, battery alert, comparison, temperature, mode, and altitude.

Computer einstellen section with a flowchart for settings: Sprache, Uhrzeit, Datum, Einheiten, Radgröße, Höhe, Gesamtwerte, Sensor, Werksreset. Includes detailed instructions for each step.

Sensoren koppeln section with a flowchart for connecting sensors: ID1, ID2, and Werksreset. Includes instructions for pairing sensors and factory resetting.

Hintergrundbeleuchtung section with instructions on how to turn the backlight on/off, stopwatches, tripmaster, and tripmaster settings.

Ruhe-/Schlafmodus section with instructions on the sleep mode, vibration sensor, and battery warning.

Tourdaten zurücksetzen section with instructions on resetting tour data and altitude selection.

Höhenauswahl section with instructions on selecting altitude and tripmaster settings.

Batteriewarnung section with instructions on battery warning and sensor battery.

Radwechsel section with instructions on wheel change and altitude selection.

Display section with image of the cycling computer screen and descriptions for clock, signal, speed, battery, temperature, and mode. Includes icons for AM/PM, signal reception, speed unit, battery alert, comparison, temperature, mode, and altitude.

Set computer section with a flowchart for settings: Language, Clock, Date, Units, Wheelsize, Altitude, Totals, Sensor, Total Reset. Includes detailed instructions for each step.

Connect sensors section with a flowchart for connecting sensors: ID1, ID2, and Total Reset. Includes instructions for pairing sensors and factory resetting.

Rest / Sleep mode section with instructions on the sleep mode, vibration sensor, and battery warning.

Reset tour data section with instructions on resetting tour data and altitude selection.

Altitude selection section with instructions on selecting altitude and tripmaster settings.

Battery alert section with instructions on battery warning and sensor battery.

Bike change section with instructions on wheel change and altitude selection.

Altitude selection section with instructions on selecting altitude and tripmaster settings.

Écran section with image of the cycling computer screen and descriptions for clock, signal, speed, battery, temperature, and mode. Includes icons for AM/PM, signal reception, speed unit, battery alert, comparison, temperature, mode, and altitude.

Configuration de l'ordinateur section with a flowchart for settings: Langue, Heure, Date, Unités, Circonférence de roue, Altitude, Valeurs totales, Capteur, Réinitialisation des paramètres. Includes detailed instructions for each step.

Couplage du capteur section with instructions on connecting sensors and battery warning.

Rest / Sleep mode section with instructions on the sleep mode, vibration sensor, and battery warning.

Reset tour data section with instructions on resetting tour data and altitude selection.

Altitude selection section with instructions on selecting altitude and tripmaster settings.

Batteriewarnung section with instructions on battery warning and sensor battery.

Change de vélo section with instructions on wheel change and altitude selection.

Altitude selection section with instructions on selecting altitude and tripmaster settings.

Configuration de l'ordinateur section with instructions for setting language, time, date, units, wheel size, altitude, totals, sensor, and factory reset.

Couplage du capteur section with instructions for connecting sensors and battery warning.

Rest / Sleep mode section with instructions on the sleep mode, vibration sensor, and battery warning.

Reset tour data section with instructions on resetting tour data and altitude selection.

Altitude selection section with instructions on selecting altitude and tripmaster settings.


Batteriewarnung section with instructions on battery warning and sensor battery.

Change de vélo section with instructions on wheel change and altitude selection.

Altitude selection section with instructions on selecting altitude and tripmaster settings.

Altitude selection section with instructions on selecting altitude and tripmaster settings.





ITALIANO

Garantiebedingungen, Terms of guarantee, Condizioni de garantie, Condiciones de la garantía, Garantiebeelingen. Includes warranty details in multiple languages.


Impostare il computer. Instructions for setting up the computer interface, including language, time, and unit settings.

Associe i sensori. Instructions for associating sensors with the device, including sensor ID and distance settings.

Retroluminazione. Instructions for the backlit display, including brightness and power settings.

Modo en espera/reposo. Instructions for the standby mode, including power saving and sensor settings.

Computer instellen. Instructions for setting up the computer, including language, time, and unit settings.



ESPAÑOL

Garantiebedingungen, Terms of guarantee, Condiciones de garantie, Condiciones de la garantía, Garantiebeelingen. Includes warranty details in multiple languages.


Impostare il computer. Instructions for setting up the computer interface, including language, time, and unit settings.

Associe i sensori. Instructions for associating sensors with the device, including sensor ID and distance settings.

Retroluminazione. Instructions for the backlit display, including brightness and power settings.

Modo en espera/reposo. Instructions for the standby mode, including power saving and sensor settings.

Computer instellen. Instructions for setting up the computer, including language, time, and unit settings.



NEDERLANDS

Garantiebedingungen, Terms of guarantee, Condiciones de garantie, Condiciones de la garantía, Garantiebeelingen. Includes warranty details in multiple languages.

Impostare il computer. Instructions for setting up the computer interface, including language, time, and unit settings.

Associe i sensori. Instructions for associating sensors with the device, including sensor ID and distance settings.

Retroluminazione. Instructions for the backlit display, including brightness and power settings.

Modo en espera/reposo. Instructions for the standby mode, including power saving and sensor settings.

Computer instellen. Instructions for setting up the computer, including language, time, and unit settings.