


CUBE & ACID HPA2000 Helmlampe vorsorglicher Austausch

Sehr geehrter CUBE Kunde,

wir möchten Sie bezüglich eines vorsorglichen Austauschs aus Sicherheitsgründen informieren. Davon betroffen ist die HPA2000 Helmlampe (Art. Nr.: 93067 & 13979).

Bei der Steckverbindung Akku-Lampenkopf kann es in Einzelfällen zu Funktionsstörungen kommen.



Bitte überprüfen Sie für einen vorsorglichen Austausch, die einwandfreie Funktion der Steckverbindung Akku-Lampenkopf.

Sollte die einwandfreie Funktion nicht gewährleistet sein, so suchen Sie Ihren Cube Fachhändler für einen vorsorglichen Austausch auf.

Überprüfen können Sie die Funktion der Steckverbindung Akku-Lampenkopf wie folgt:



Nehmen Sie Ihre HPA2000 Lampe nach Bedienungsanleitung in Betrieb. Bewegen und Biegen Sie die Kabel beidseitig an der Steckverbindung.

Sollte dadurch die Lichtabgabe ausfallen, so ist die Funktion nicht einwandfrei gewährleistet.

Bei einer nicht eindeutig möglichen Beurteilung der Funktionsfähigkeit suchen Sie zu einer genauen Prüfung Ihren Cube Fachhändler auf.

Bei Fragen dürfen Sie uns jederzeit kontaktieren: hpa2000@cube.eu

Wir danken Ihnen für Ihr Verständnis und entschuldigen uns im Voraus für die entstandenen Unannehmlichkeiten.


Mit freundlichen Grüßen,
Ihr CUBE-Team

CUBE & ACID HPA2000 helmet lamp precautionary replacement

Dear CUBE customer,

we would like to inform you about a precautionary replacement due to safety reasons. This affects the HPA2000 helmet lamp (Art. No: 93067 & 13979).

In individual cases, malfunctions may occur with the plug-in connection of the battery and the lamp head.



For precautionary replacement, please check the proper function of the plug connection between battery and lamp head.

If it doesn't work properly, please contact your Cube dealer for a precautionary replacement.

You can check the function of the battery and lamp head connector in the following way:



Activate your HPA2000 lamp according to the instruction manual. Then move and bend the cables on both sides of the connector.

If the light goes out as a result, then it's likely the product is not operating correctly.

Should it not be possible to make a clear assessment of the functionality, please contact your local Cube dealer and ask for a detailed inspection.

Should you have any further questions, please feel free to contact us at any time at: hpa2000@cube.eu

We would like to thank you for your understanding and apologize in advance for any inconvenience caused.

Best regards,
Your CUBE team